


EPSON

Home Projector

EMP-TW700

dreamio™






EN	Quick Start Guide	BG	Ръководство за бърз старт
DE	Kurzanleitung	RO	Ghid de pornire rapidă
FR	Guide de démarrage rapide	EE	Lühijuhend
IT	Guida di avvio rapido	LV	Ātrās darba uzsākšanas pamācība
ES	Guía de inicio rápido	LT	Trumpas pradžios vadovas
PT	Guia de Referência Rápida	EL	Οδηγός γρήγορης εκκίνησης
NL	Introductiehandleiding	TR	Hızlı Başlangıç Kılavuzu
DA	Introduktion	SL	Priročnik za hitri zagon
FI	Pika-aloitusopas	HR	Kratke upute
NO	Hurtigveiledning	MK	Прирачник брз почеток
SV	Snabbstartsguide	SR	Uputstvo za brz početak
CS	Úvodní příručka	RU	Руководство по быстрой установке
HU	Bevezetés	AR	دليل البداية السريعة
PL	Przewodnik szybkiego startu	FA	راهنمای سریع برای شروع بکار
SK	Stručná príručka		

EN	For detailed information, refer to the User's Guide.
DE	Ausführliche Informationen finden Sie im Benutzerhandbuch.
FR	Pour plus d'informations, reportez-vous au guide utilisateur.
IT	Per informazioni dettagliate, consultare la guida per l'utente.
ES	Para obtener información detallada, consulte la guía del usuario.
PT	Para mais informações, consulte o Manual do Utilizador.
NL	Raadpleeg de gebruikershandleiding voor uitgebreide informatie.
DA	Se brugervejledningen for at få yderligere oplysninger.
FI	Lisätietoja on käyttöoppaassa.
NO	Hvis du vil ha mer detaljert informasjon, kan du se brukerhåndboken.
SV	Detaljerad information finns i användarhandboken.
CS	Podrobné informace naleznete v Uživatelské příručce.
HU	Részletes ismertetés a Használati útmutatóban található.
PL	Szczegółowe informacje zawiera Przewodnik użytkownika.
SK	Podrobné informácie nájdete v Príručke používateľa.


BG	За подробна информация направете справка с Ръководството за потребителя.
RO	Pentru informații detaliate, consultați User's Guide (Ghidul utilizatorului).
EE	Täpsemat teavet vt kasutusjuhendist.
LV	Sīkāka informāciju skatīt lietošanas instrukcijā.
LT	Detalios informacijos ieškokite Vartotojo vadove.
EL	Για περισσότερες πληροφορίες, δείτε τον Οδηγό χρήσης.
TR	Ayrıntılı bilgi için Kullanım Kılavuzuna başvurun.
SL	Podrobnejše informacije lahko najdete v navodilih za uporabo.
HR	Detaljnije informacije, potražite u vodiču za korisnike.
MK	За подетални информации видете во Упатството за чпотреба.
SR	Za detaljnije informacije pogledajte Korisničko uputstvo.
RU	Для получения дополнительной информации см. Руководство пользователя.
AR	للحصول على المعلومات التفصيلية، ارجع إلى "دليل المستخدم".
FA	برای اطلاعات مشروح به راهنمای کاربر رجوع شود.

EN	Content of the box
DE	Packungsinhalt
FR	Contenu de la boîte
IT	Contenuto della confezione
ES	Contenido del paquete
PT	Conteúdo da embalagem
NL	Inhoud van de doos
DA	Æskens indhold
FI	Laatikon sisältö
NO	Innholdet i esken
SV	Innehåll i lådan
CS	Obsah balení
HU	A doboz tartalma
PL	Zawartość opakowania
SK	Obsah balenia


BG	Съдържание на кутията
RO	Conținutul cutiei
EE	Kasti sisu
LV	Komplektācija
LT	Dėžės turinys
EL	Περιεχόμενα της συσκευασίας
TR	Kutunun içeriği
SL	Vsebina paketa
HR	Sadržaj paketa
MK	Содржина на кутијата
SR	Sadržaj kutije
RU	Содержимое упаковки
AR	محتوى الصندوق
FA	محتویات جعبه








16 : 9








4 : 3










3







4






5




6

①


OFF




②



x2



④



③

OFF



30 Sec.

